Magnum Drain Line Flow Control

Drain Line Flow Control Figure A

The rubber flow washers (3) and plugs must be assembled to the retainer (2) as shown. Install the retainer O-ring (1) into the O-ring groove on the opposite side of the retainer.




Figure A

Magnum Drain Line Flow Control

Drain Line Flow Control Figure A (1)

The rubber flow washers (3) and plugs must be assembled to the retainer (2) as shown. Install the retainer O-ring (1) into the O-ring groove on the opposite side of the retainer.

Installation Procedure




Figure A

Installation Procedure Figure B

The drain line flow control (1) must be installed to the valve as shown with the flow washers facing the valve. The O-ring seats against the plumbing adapter (2).




Figure B

Note: Hand tighten all plumbing connections initially. Tighten no more than 1/4 turn past hand tight if required. The drain line flow control (1) must be installed to the valve as shown with the flow washers facing the valve. The O-ring seats against the plumbing adapter (2).

Figure B




Figure B

Note: Hand tighten all plumbing connections initially. Tighten no more than 1/4 turn past hand tight if required.

©2009 Pentair Residential Filtration, LLC P/N 3014228 Rev B MA09 ©2009 Pentair Residential Filtration, LLC P/N 3014228 Rev B MA09